

AIR CLEANING BLOWERS[™]

SELF CLEANING- NO FILTER ELEMENTS TO MAINTAIN

ACB MODEL T5

Clean Air Out



AIR FLOW: 400-500 CFM

UNIT TECHNICAL SPECIFICATIONS -

Standard Electrical Options:	Amperage of	Componer	nts:	
(other Configurations Available Upon Request)	Voltage	FLA	<u>MCA</u>	MOP
 115 Volts / 60 Hz / 1Phase 208-230 Volts / 60 Hz / 1 Phase 	115/1/60	14A	18A	30A
	208-230/1/60	6.4A	8A	15A
• 208-230 Volts / 60 Hz / 3 Phase	208-230/3/60	4.2A	5.3A	15A
• 460 Volts / 60 Hz / 3 Phase & 380-420 Volts / 50 Hz / 3 Phase	460/3/60	3A	3.8A	15A

Most units can run on 50Hz current, without adaptation, but with reduced capacity and RPM. Additional models available to operate on special voltages.

Standard models are 18-gauge steel cabinets and a 12-gauge mounting plate. Metal material options: Aluminum, 304 Stainless Steel or 316 Stainless Steel.

Inlet hoods are removable to facilitate installation, but necessary for safe functioning of the standard units, unless directly connected to duct work.


Selkirk, NY 12158, USA

Units meet IP54 or higher standard. They can meet NEMA 4X standard if made of type 304 or type 316 stainless steel and appropriate material for impeller.

		AFFLICA		
Manufacturing	Medical	Data Center / Clean Rooms	Mining / Oil / Tunneling	Office / Corporate
Food Processing	Military / Government	Agriculture	Transportation	School / Institution
Air Cleaning Blow	vers, LLC 1521 US H	WY 9W BLDG 4 C/D,	www.AirCleaningBlowers.com	+1 (518) 635-4169

1

AIRFLOW PERFORMANCE



* All values labeled in the graph and table are estimates.

Point	Power Supply ∨	Frequency Hz	Airflow CFM	Pressure IN H20.
1	460	60	632	0.0
2	460	60	522	0.5
3	460	60	426	0.9
4	460	60	224	1.7
5	460	60	0	2.8

OPTIONS

Heating Elements	1.5 to 20 kW of electrical-resistance heat using corrosion-resistant tubular incoloy elements (not light-weight wires).
Collecting Particles	In the case that the material being removed from the air or other gas has value, various adaptations can channel the material to a collection point. For some models, ACB can offer optional, reusable particle-collection bags.
Housing for Downstream Specialty Filter Media	Activated carbon and other chemical-removing bulk media or filter elements to remove finer particles than the ACB removes.
Thermostat	To control the airflow or to warn user of high or low temperatures.
Adaptation for Installation On/In Vertical and other Air Conditioners	Provide changes of air and/or pressurization and purging to enclosures served by the Air Cleaning Blowers [™] .
Hazardous-Area Controls	To provide NFPA Type X, Y, or Z purging and pressurization.

NEC Class I Groups A, B, C, or D, Class II Groups F or G, or Class III Division/Zone 2 or Class I Groups C or D, Class II Groups E, F, or G, or Class III, Division/Zone 1 or 2 and their ATEX and IECEx equivalents.



Adaptation for Hazardous

(Explosive) Ambients

Air Cleaning Blowers[™], LLC

www.AirCleaningBlowers.com +1 (518) 635-4169 1521 U.S Route 9W Building 4C/D Selkirk, NY 12158 ACB units typically bolt to a wall. They require no additional support, unless the wall cannot support the weight indefinitely. When ACBs are installed on a wall, the passage through the wall can be lined with a duct, if desired. These units are designed to connect directly to standard sized ducting and their flanges. Most units come equipped with a cord for connection to a junction box.

Inside/through-the-wall options are also available.

0

0

0

0

33.75°

11.25°

1

Ø18.1in

[46.0cm]

STANDARD

ARRANGEMENT ONLY

0

CLEAN-AIR OUTLET

(LOW-PROFILE OPTION)

 $\begin{array}{l} \hline \hline CONNECTION BOLT PATTERN \\ \hline \phi .4 in [$ 01.1 cm] THRU, 8 PLACES, \\ EQUALLY SPACED, AS SHOWN, \\ ON A $ $ 17.0 in [$ 43.2 cm] B.C. \\ \hline \end{array}$

15.6in

39.7cm

LOW-PROFILE

OPTION ONLY

0

0

0

0

0

THIS HOLE NOT INCLUDED ON LOW-PROFILE OPTION

E

0

0

9.1in


23.0cm

0

0

0

0





CLEAN-AIR OUTLET (STANDARD ARRANGEMENT)

Air Cleaning Blowers[™], LLC

www.AirCleaningBlowers.com +1 (518) 635-4169

1521 U.S Route 9W Building 4C/D Selkirk, NY 12158



AIR CLEANING BLOWERSTM SELF CLEANING- NO FILTER ELEMENTS TO MAINTAIN

Build Your Own Model (Number):

In order to properly specify your ACB, you must make selections in each of the categories: electrical, heat, cabinet material, impeller material, exterior finish, and hazardous location. The only category that is completely optional is "additional options" and it can be ommitted if you do not have any special needs.

The electrical codes available for your ACB specification are: A, B, C, E, F, G, H and X. Select your electrical configuration using one of the codes listed below (). Next select a code for your desired heat option ().


 The unit is made up 18 gauge material, with the choice of code(s): A, 4, 6, T (
) and with your choice of finish (
).

 The impeller material is (
). Note the impeller material most common for this model is code(s): A.
 A.

Next select the desired hazardous (explosive) - location rating if applicable (your Air Cleaning Blower[™].). This will complete the mandatory fields necessary to order or specify

You can browse through the additional options / special conditions / custom modifications and select and add a code based on your additional needs, if any.

Choose your model by filling out the blanks with the appropriate code from the list below!



4